

Commercial Driveway Sidewalk Crossings

- 4,000 psi concrete
- 5' wide
- 6" thick
- Tooled joint every 5'
- Install an expansion joint every 20' and on each edge of driveway. Use ½" soft board for the expansion joint.
- Edges tooled
- Light brush finish
- Existing asphalted driveways must be saw-cut.
- Over-excavation must be made be good with compacted imported aggregate (*base course stone/crusher run*).
- After construction, site must be cleaned, excavated soil removed, and area left free of debris and obstructions.